

HY-BRID LIFTS™

BY CUSTOM EQUIPMENT LLC

OPERATIONS & SAFETY MANUAL
PUSH-AROUND AERIAL WORK PLATFORM

SUPO-642
REV A



HB-P527

SERIES I

Original instructions are written in English.

The purpose of this Operations and Safety manual is to provide users with the instructions and operating procedures essential to properly and safely operate the Custom Equipment Hy-Brid Lift for its intended purpose, and to position personnel and their necessary tools and materials.



**THE OPERATION AND SAFETY MANUAL MUST BE
READ AND UNDERSTOOD PRIOR TO OPERATING THE MACHINE.**


- The user/operator should not accept operating responsibility until the manual has been read and understood as well as having operated the lift under supervision of an experienced and qualified operator.
- Because the manufacturer has no direct control over machine application and operation, proper safety practices are the responsibility of the user and all operating personnel.



**ANY MODIFICATION ON THIS MACHINE WITHOUT THE EXPRESS WRITTEN CONSENT OF THE
MANUFACTURER IS PROHIBITED.**

Fall protection notice:

The guardrail system around the perimeter of the platform is the fall protection system for push-around elevating work platforms per the ANSI/SIA A92.3 Standard. It is prohibited to use an Aerial Work Platform manufactured by Custom Equipment, LLC. With any portion—or all—of the guardrails removed. Lanyard anchorage points on this type of equipment are not required to conform to the applicable standard. However, if anchorage points for lanyard attachments are required by site authorities or other regulations, the anchorage points on all equipment manufactured by Custom Equipment, LLC. Are recommended to be used for work positioning restraints of personnel only. Lanyard lengths are to be determined by operator/owner to restrict the operator to the confines within the guardrail system.



**USE OF FALL ARREST SYSTEMS ATTACHED TO ANCHORAGE POINTS
ON EQUIPMENT MAY CAUSE MACHINE TO TIP, RESULTING IN SERIOUS INJURY OR DEATH.**

TABLE OF CONTENTS

NOTES.....	2
FOREWORD	3
TABLE OF CONTENTS	4
INDEX OF FIGURES.....	5
SECTION 1 SAFETY	6
1.1 SAFETY SYMBOLS.....	6
1.2 GENERAL RULES AND PRECAUTIONS	6
1.3 SAFETY FEATURES	7
1.4 SAFETY CONTROLS	7
1.5 MAINTENANCE LOCK	8
1.6 SAFETY GUIDELINES.....	9
SECTION 2 PRODUCT DESCRIPTION.....	10
2.1 GENERAL.....	10
2.2 STANDARDS CONFORMITY	10
2.3 MACHINE SPECIFICATIONS.....	10
SECTION 3 DECALS	12
3.1 DECAL LOCATION.....	12
SECTION 4 TRANSPORT HANDLING & STORAGE	14
4.1 PRELIMINARY UNPACKING AND DEALER INSPECTION	14
4.2 STORAGE.....	14
4.3 TRANSPORTATION	14
4.4 LIFTING AND TIE-DOWN POINTS.....	14
4.5 FORK LIFT POCKETS	15
SECTION 5 OPERATION	16
5.1 PRE-START INSPECTION	16
5.2 CONTROLS	16
5.3 STARTUP/SHUT DOWN	17
5.4 ELEVATING AND LOWERING	17
SECTION 6 DAILY MAINTENANCE.....	18
6.1 CHARGING THE BATTERY	18
SECTION 7 PRE-START INSPECTION CHECKLIST.....	20
7.1 PRESTART INSPECTION CHECKLIST	20
NOTES.....	22

INDEX OF FIGURES

FIGURE 1: E-Down Location 7
FIGURE 2: E-Down Symbol 7
FIGURE 3: Maintenance lock use..... 8
FIGURE 4: Maintenance lock storage 8
FIGURE 5: Rear Brakes 14
FIGURE 6: Tie-Down Points 14
FIGURE 7: Center of Gravity 15
FIGURE 8: Base Controls..... 16
FIGURE 9: Platform Controls 16
FIGURE 10: Master Power Switch 17
FIGURE 11: Battery Charger LED Display 19

Revisions:

Rev A: Initial Release.....September 2015

SECTION 1 | SAFETY

1.1 | SAFETY SYMBOLS



FAILURE TO FOLLOW THIS WARNING WILL CAUSE DEATH OR PERSONAL INJURY.

“DANGER” indicates an imminently hazardous situation, which, if not avoided, will result in death or serious injury.



FAILURE TO FOLLOW THIS WARNING MAY CAUSE DEATH OR PERSONAL INJURY.

“WARNING” indicates a potentially hazardous situation, which, if not avoided, could result in death or serious injury



FAILURE TO FOLLOW THIS WARNING MAY CAUSE INJURY OR DAMAGE TO EQUIPMENT.

“CAUTION” indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury or damage to equipment

1.2 | GENERAL RULES AND PRECAUTIONS

Custom Equipment, LLC designed the Hy-Brid Lift push-around scissor lift to be safe and reliable. It is intended for elevating personnel, along with their necessary tools and materials to overhead work locations. Vibration does not create significant hazards on this machine.

An operator of any type of work platform is subject to certain hazards that cannot be protected by mechanical means. It is therefore essential that operators be competent, careful, physically and mentally fit, and thoroughly trained in safe operation of this machine. Although Custom Equipment, LLC conforms to specified ANSI & OSHA requirements, it is the responsibility of the owner to instruct operators with the safety requirements made not only by Custom Equipment, LLC, but by the various safety boards in your area, as well as additional requirements set forth by ANSI & OSHA. If you come across a situation that you think might be unsafe, stop the platform and request further information from qualified sources before proceeding.



NEVER REACH BETWEEN SCISSOR LINKS OR PROP UP PLATFORM



WHEELS EXTENDING BEYOND THE SIDES OF THE BASE MAY OCCUR IN TIGHT TURNING SITUATIONS.

1.3 | SAFETY FEATURES

- Puncture-proof wheels.
- Guardrails—43.83 in height with 6 in kick plates
- Non-slip deck.
- Entrance gate.
- Automatic brake when elevated
- Free descent protection. A pressure compensated flow control valve is installed in the hydraulic circuit to prevent the platform from descending in case of a ruptured hydraulic hose. The platform is hydraulically locked with a check valve and has controlled descent when valve activates.
- Decals. Danger, Caution, and Warning decals are displayed at various locations on this unit
- Key Switch Security. A key switch is required to prevent unauthorized use.

1.4 | SAFETY CONTROLS

Descent — Manual Override

For manually lowering the scissors, a manual valve is provided. To lower the scissors, pull the cable located near the front of the machine.




FIGURE 1: E-Down Location




FIGURE 2: E-Down Symbol



IF PLATFORM SHOULD FAIL TO LOWER, DO NOT ATTEMPT TO CLIMB DOWN THE BEAM ASSEMBLY. SERIOUS INJURY MAY RESULT. HAVE AN EXPERIENCED OPERATOR USE THE EMERGENCY LOWERING PROCEDURE TO SAFELY LOWER THE PLATFORM.

Emergency Stop

This lift is equipped with two emergency stop switches, one at the platform control and one at the base control, that when activated, will render the unit inoperable until reset. To reset, pull the button out.



PUSHING THE EMERGENCY STOP BUTTON WILL STOP MOVEMENT IMMEDIATELY. THIS MAY CAUSE UNEXPECTED PLATFORM MOVEMENT AS THE MACHINE COMES TO A SUDDEN STOP. BRACE YOURSELF AND SECURE OBJECTS ON THE PLATFORM DURING OPERATION OF THE MACHINE.

1.5 | MAINTENANCE LOCK

The maintenance lock must be placed into position whenever the machine is being serviced in a partially raised position. Serious injury and/or death could result if maintenance lock is not used properly.




FIGURE 3: Maintenance lock use




FIGURE 4: Maintenance lock storage

1.6 | SAFETY GUIDELINES

- Only qualified operators may operate this unit.
- All operators must read and understand the Operation and Safety Manual. They must understand all decals and warning labels on unit.
- Do not work on platform if your physical condition is such that you feel dizzy or unsteady in any way.
- Do not neglect/misuse machine. Report any misuse of equipment to proper personnel.
- Prevent unauthorized use; when unit is not in use, remove key.
- It is recommended all personnel on unit wear approved personal protective equipment (PPE), i.e. head gear.
- Use machine only for purposes for which it was intended.
- Lift should never be used as a crane.
- Do not exceed the load capabilities of the platform.
- Distribute load evenly over platform floor area.
- Never use unit as electrical grounds for arc welding.
- Do not override any hydraulic, mechanical, or electrical safety devices.
- Check job site for unsafe working conditions.
- Watch out for others. Keep others clear of operating platform. Never allow others to pass under a raised platform or position the platform over someone.
- Avoid contact with fixed (buildings, etc.) or moving (vehicles, cranes, etc.) objects. Check work area for overhead obstructions or possible hazards.
- Follow any applicable national traffic regulations.
- Use indoors only. Lift is not designed for windy conditions or electrical storms.
- Unit must be on hard level surface before elevating. Do not operate on incline or uneven surface.
- You must maintain a clearance between any part of the machine, or its load, and any electrical line or apparatus. Follow local power line clearance regulations.
- You must maintain a clearance between any part of the machine, or its load, and any electrical line or apparatus. Follow local power line clearance regulations.



DO NOT OPERATE MACHINE NEAR POWER-LINES. THE PLATFORM AND ENCLOSURES ARE NOT INSULATED. EQUIPMENT IS ONLY AS SAFE AS OPERATOR.

- Do not use ladders or scaffolding on the platform to obtain greater height.
- Do not enter or exit platform while machine is in motion.
- Never mount or dismount a raised platform.
- Make sure entry gate is secured before operating machine from the platform.
- Never belt or tie off to an adjacent structure.
- Secure tools and materials.
- Personnel must maintain a firm footing on the platform floor and work only within the platform area.
- Before operation, ensure that the machine is properly serviced.
- Do not use machine if it is not working properly.
- Make sure platform rails and pins are secured.
- Operator shall use the maintenance lock when performing all types of maintenance procedures.
- Do not smoke while charging the battery.

SECTION 2 | PRODUCT DESCRIPTION

2.1 | GENERAL

Custom Equipment's Hy-Brid Scissor Lift is an aerial work platform designed to be safe and reliable. The purpose of the machine is to elevate personnel, along with their necessary tools and materials. The machine is intended for indoor use (no wind load). Manufacturer approval is required for any use other than the intended use.

2.2 | STANDARDS CONFORMITY

Model HB-P527 S1 has been assessed, tested and approved in accordance with the requirements of ANSI/SIA A92.3-2006 and CAN-SCA B354.1-04-2005.

Manufacturer:
Custom Equipment, LLC
2647 Hwy 175
Richfield, WI 53076
USA
Phone: +1-262-644-1300
Fax: +1-262-644-1320
www.hybridlifts.com


2.3 | MACHINE SPECIFICATIONS

Working Height (maximum)	11.3	ft.	3.4	m
Platform Height (maximum)	5.3	ft.	1.6	m
Platform Height (minimum)	20.3	in.	51.5	cm
Stowed Height	63.6	in.	161.5	cm
Ground Clearance Lowered	2.5	in.	6.4	cm
Overall Length	41.0	in.	104.1	cm
Overall Width	26.6	in.	67.6	cm
Platform Length (Retracted, Inside)	37.0	in.	94.0	cm
Platform Width (Retracted, Inside)	22.0	in.	55.9	cm
Platform Extension	N/A	in.	N/A	cm
Guard Rail Height	43.8	in.	111.3	cm
Step Height	20.3	in.	N/A	cm
Wheel Base	33.1	in.	84.1	cm
Wheel Track	22.1	in.	56.2	cm
Tire Size -Front	8.0	in.	20.3	cm
Tire Size -Rear	8.0	in.	20.3	cm
Turning Radius (Inside)	ZERO	IN.	ZERO	CM
Turning Radius (Outside)	39.4	IN.	100	CM
Gradeability (Stowed Position)	N/A	N/A	N/A	N/A
Drive Speed Max (Platform Elevated)	N/A	N/A	N/A	N/A
Drive Speed Max (Platform Lowered)	N/A	N/A	N/A	N/A
Lift/Lower Speed	9/12	SEC	9/12	SEC

Power System-Voltage	12V DC			
Batteries-Deep Cycle Marine	(1) 12V GROUP 24 AGM			
Hydraulic Pressure (max)	650.0	psi	4481.6	kPa
Hydraulic Fluid Capacity	0.3	gal	1.2	L
Platform Capacity	500.0	lb.	226.8	kg
Rated Occupancy	1.0	Persons	1.0	Persons
Extension Capacity	N/A	N/A	N/A	N/A
Horizontal/Manual Force	45.0	LB	200	N
Wind	INDOOR USE ONLY/NO WINDY CONDITIONS			
Rated Slope	LEVEL SURFACE			
Tilt Sensor Activated	N/A			
Temperature	-4°F to -104°F		-20°C to 40°C	
Vibration	8.2 ft / s ² max		2.5 m / s ² max	
Sound	86 dB Normal Use/100 dB Alarms			
Machine Weight (Unloaded) (Approx.)	575.0	lb.	260.8	kg
Minimum Wheel Load-Contact Pressure	115.0	psi	792.9	kPa
Maximum Wheel Load-Contact Pressure	215.0	psi	1482.4	kPa
Minimum Machine Loading-Floor Pressure	75.8	psf	3.6	kPa
Maximum Machine Loading-Floor Pressure	141.9	psf	6.8	kPa

SECTION 3 | DECALS

3.1 | DECAL LOCATION



Item #	Part Number	Decal Meaning or Designation	Qty.
1	N/A	SERIAL NUMBER	1
2	N/A	SERIAL NUMBER REFERENCE	1
3	DE727	DECAL,KEEP	2
4	DE728	DECAL,CLEAR	2
5	DE600E-14	DECAL,MAINT LOCK	1
6	DE751	DECAL,E-DOWN CABLE	1
7	DE601	DECAL,LOGO HY-BRID	1
8	DE746	DECAL,LANYARD ATTACHMENT	1
9	DE666	DECAL, LWR	1
10	DE675	DECAL,NO FORK	1
11	DE706	DECAL,UPR HB	1
12	DE726	DECAL,CAPACITY,500#,1P,I,WO/SO	1
13	DE730	DECAL,OL ALARM	1
14	DE603-14	MODEL# DECAL-HB-P527	2
15	DE760	DECAL,E-STOP HANDLE	1
16	DE673	DECAL,HYDR FLUID	1
17	DE674	DECAL,HYDR FLUID	1
18	DE669	DECAL, CONTROL UPR	1

SECTION 4 | TRANSPORT HANDLING & STORAGE

4.1 | PRELIMINARY UNPACKING AND DEALER INSPECTION

Maintenance locks must be engaged prior to inspecting or servicing the unit when the platform is elevated. Inspect machine for any possible damage during shipment; perform a pre-delivery inspection. See checklist in the Maintenance Manual. Reset emergency stop switches, if necessary.

4.2 | STORAGE

After periods of storage, exposure to extremes of ambient conditions—heat, cold, moisture, dust etc., inspect the machine. Refer to the Pre-Delivery/ Frequent Inspection Checklist in the Maintenance Manual.

4.3 | TRANSPORTATION

Lower the work platform to the down position. Turn key switch to off position. For safety and controlled handling, it is not recommended to move the unit on a slope greater than 5°. Check entire machine for loose or unsecured items. Remove any loose items from machine. Apply manual brake lock on rear wheels.




FIGURE 5: Rear Brakes

4.4 | LIFTING AND TIE-DOWN POINTS

Lower the work platform to the down position. Turn key switch to off position. For safety and controlled handling, it is not recommended to move the unit on a slope greater than 5°. Check entire machine for loose or unsecured items. Remove any loose items from machine. Apply manual brake lock on rear wheels. Tie-down points are provided in the front and rear of the machine for securing the machine on a trailer or truck bed for transport between places of use. They may also be used as lift points.





FIGURE 6: Tie-Down Points

4.5 | FORK LIFT POCKETS

Fork lift pockets are provided on the side of the unit for loading and unloading. Do not use a forklift under-neath the machine from the back. When moving machine with a forklift, do not let machine slide along floor. Bring forklift to a stop and then gently lower the machine.



Center Of Gravity	X Axis	Y AXIS
HB-P527	21.5 in.	15 in.

FIGURE 7: Center of Gravity

SECTION 5 | OPERATION

5.1 | PRE-START INSPECTION

Before use each day or at the beginning of each shift, the machine shall be given a visual inspection and functional test. Repairs (if any) must be made prior to operating the machine, as it is critical to ensure safe operation of the machine. A checklist for pre-start inspection can be found in the back of this manual.

5.2 | CONTROLS




FIGURE 8: Base Controls

Item #	Control/Indicator
1	Master Power Switch/Emergency Stop




FIGURE 9: Platform Controls

Item #	Control/Indicator
1	Lift Enable Button Operation described as follows.
2	Overload LED : Not active on this mode;
3	Emergency Stop Operation described in Safety Controls
4	Up / Down Rotary Switch Operation described as follows.
5	Beeper Alarm Alarm sounds for descent.

5.3 | STARTUP/SHUT DOWN

Check that the work area is safe.

It is not recommended to maneuver the unit on a slope greater than 5°. Check that master power switch is in "ON" position. Ensure that the key in the lower control panel is in the "ON" position for the chassis or platform control. Machine must be on a hard, level, surface before operation. Check that bubble level is centered. Engage the manual brakes on the rear casters before elevating the platform. Enter the work platform in the stowed position using the constant three point contact method. Follow all general rules and precautions stated in this manual. When finished with the machine, place the platform in the stowed position. Carefully exit the platform using the constant three point contact method.




FIGURE 10: Master Power Switch

When finished with the machine, place the platform in the stowed position.

Carefully exit the platform using the constant three point contact method. **NEVER JUMP OFF THE PLATFORM**
Park the machine on a level surface.

Turn master power switch to off position. To prevent unauthorized use, remove the key from the master power switch. The key may be placed in the manual pouch and the cabinet padlocked to secure the machine in the isolated position.



**THE OPERATOR MUST BE AWARE OF THE ENVIRONMENT. DO NOT RAISE
THE PLATFORM IF THE MACHINE IS NOT ON A FIRM, LEVEL SURFACE.**

5.4 | ELEVATING AND LOWERING

Using Upper Platform Controls

Make sure the platform controls are selected with the selector switch at the base controls. To raise or lower the platform, press the Elevate/Lower Enable Button. While holding down the Enable Button, rotate and hold the Elevate/Lower switch until the platform is in the desired position.

SECTION 6 | DAILY MAINTENANCE



FAILURE TO PERFORM INSPECTIONS AND PREVENTATIVE MAINTENANCE AT RECOMMENDED INTERVALS MAY RESULT IN THE UNIT BEING OPERATED WITH A DEFECT THAT MAY RESULT IN INJURY OR DEATH OF THE OPERATOR. REGULAR INSPECTION AND CONSCIENTIOUS MAINTENANCE IS IMPORTANT TO EFFICIENT ECONOMICAL OPERATION OF THIS MACHINE. IT WILL HELP TO ASSURE THAT EQUIPMENT WILL PERFORM SATISFACTORILY WITH A MINIMUM OF SERVICE AND REPAIR. MAKE CHECKS AT THE STATED INTERVALS OR MORE FREQUENTLY IF REQUIRED BY LOCAL OPERATING CONDITIONS. A PRE-START INSPECTION CHECKLIST IS INCLUDED IN THIS MANUAL.

Additional maintenance for use by trained personnel is included in a separate Maintenance Manual. Refer to the Maintenance Manual for Pre-Delivery/Frequent and Monthly Checklists and replacement part information.

6.1 | CHARGING THE BATTERY

This unit is equipped with a deep cycle 12-volt battery. The care and maintenance of your battery has much to do with how well this unit functions. Battery wiring should be checked monthly.

NOTE: The surrounding temperature greatly affects the power reserve within a battery.

EXAMPLE: A battery that is 100% charged at 80° F (27°C) drops to 65% at 32°F (0°C). At 0°F (-18°C), this battery will drop to 40% efficiency.



LEAD-ACID BATTERIES GENERATE EXPLOSIVE GASES. KEEP SPARKS AND FLAME AWAY FROM BATTERIES. DO NOT SMOKE WHILE CHARGING.

Do not operate unit while charging. Shortened battery life will result.

To Charge:

Park the machine on a level surface.

Plug charger into AC outlet until charged.

For best battery life, leave charger plugged in until machine will be used again. The charger will maintain the battery charge.

The charger will not begin the charging cycle on severely discharged batteries.



DO NOT OPERATE UNITE WHILE CHARGING



NEVER ADD ACID TO THE BATTERY













FIGURE 11: Battery Charger LED Display

Battery solution is at its proper strength when the battery is manufactured. Use distilled water and keep fluid up to proper level. When required, water should be added to battery after charging, unless water level is below the plates.

Reading the battery displays

<p>POWER</p>  <p>Green LED (ON)</p>	<p>BATTERY 1 STATUS</p> <p>CHARGING READY</p>  <p>Red LED (OFF)</p>  <p>Green LED (ON)</p>	<p>This display indicates that the power is on but there is no connection to a battery. The charger must see approximately five (5) volts on a battery to deliver D/C current.</p>
<p>POWER</p>  <p>Green LED (ON)</p>	<p>BATTERY 1 STATUS</p> <p>CHARGING READY</p>  <p>Red LED (ON)</p>  <p>Green LED (OFF)</p>	<p>This display indicates that power is on and that both outputs are delivering D/C current to the batteries</p>
<p>POWER</p>  <p>Green LED (ON)</p>	<p>BATTERY 1 STATUS</p> <p>CHARGING READY</p>  <p>Red LED (OFF)</p>  <p>Green LED (ON)</p>	<p>This display indicates that power is on and that the output is finished charging and is in a float maintenance model.</p>

SECTION 7 | PRE-START INSPECTION CHECKLIST

7.1 | PRESTART INSPECTION CHECKLIST



THIS CHECKLIST MUST BE USED AT THE BEGINNING OF EACH SHIFT OR AFTER EVERY SIX TO EIGHT HOURS OF USE. FAILURE TO DO SO COULD AFFECT THE SAFETY OF THE OPERATOR.

Model Number: _____ **Serial Number:** _____

Keep inspection records up-to-date.
Record and report all discrepancies to your supervisor.
A dirty machine cannot be properly inspected.

Y – Yes/Acceptable N – No/Unacceptable R – Repaired

Description	Y	N	R
Visual Inspections			
Check that there are no damaged, dented, or bent structural members.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
There are no loose or missing parts.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Check that warning and instructional labels are legible and secure. Ensure that load capacity is clearly marked.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Check the platform rails and safety gate for damage.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Platform and base controls are not missing, damaged, or disconnected.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Electrical cables and wires are not torn, frayed, or disconnected.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Hydraulic hoses are not torn or loose, and there are no leaks. Check that hoses and cables have no worn areas or chafing.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Check the tires for damage.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Check that all snap rings are secure in grooves on pivot pins.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Functional Tests			
Gate closes automatically and latches (alignment can be adjusted with screw-on toe board or railing).	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Platform Controls – Check all switches and push buttons for proper operation:			
Emergency Stop (stops all movement)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Up/Down Controls (Elevates, Lowers, Enable button must be pressed)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Base Controls – Check all switches and push buttons for proper operation:			
Emergency Stop (stops all movement)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Key Switch (Selects Platform Control, Ground Control, or Off)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Alarm (Not damaged, sounds for descent)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Up/Down Rocker Switch (Elevates, Lowers)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Wheels: Front and rear wheels rotate freely.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Brakes engage and hold when platform is elevated.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

DATE _____ INSPECTED BY _____

THIS PAGE WAS INTENTIONALLY LEFT BLANK

HY-BRID LIFTS™

BY CUSTOM EQUIPMENT LLC

Push-Around Aerial Work Platform
Operations & Safety Manual
HB-P527

© 2015 Custom Equipment, LLC
2647 Highway 175
Richfield, WI 53076
U.S.A.
Tel.: +1-262-644-1300
Fax: +1-262-644-1320
www.hybridlifts.com
Service@Customequipmentlifts.com

"Hy-Brid Lifts" is a trademark of Custom Equipment, LLC.
These machines comply with specified ANSI & CSA requirements

Revision Date: September 2015

Printed In The USA